



**How to authorize a AX HYBRID PRO 2.0 on HC
to HPP**

| | | | | | |
|-----------------|--|-----------------|------------------------------------|--------------|------------|
| Title: | How to authorize a AX HYBRID PRO 2.0 on HC to HPP | Version: | V2.1.0 250123 and later version | Date: | 25/03/2025 |
| Product: | AX HYBRID PRO 2.0 | | | Page: | 1 of 6 |


Preparation

- 1. Download Hik-Connect and Hik-Partner Pro on your phone.
- 2. Finish adding AX HYBRID PRO 2.0 on HC.


How to authorize a AX HYBRID PRO 2.0 on HC to HPP

1. Configuration on the HC side.



- 1) Go to the configuration screen of the device.




- 2) Scroll down to the bottom and click on **Authorization Service**.




3) Click on **Service Provider** → Click on **Add Service Provider**



- 4) Enter the HPP account email address or scan the QR code provided by HPP.




- 4) Click on the icon in the figure below to select which privileges to give to the HPP account.




Note:

User Management: Choose which users HPP can manage.




System Management:




4) After selecting the permissions, click OK.

A notification will be automatically sent to the HPP account, waiting for the HPP side to pass the invitation.





2. Configuration of the HPP side.


- 1) Click on the message notification in the upper right corner of the home page.



- 2) You can see the **Site Message**, click on it and click **I Agree**.







See Far, Go Further