

Amazon Alexa: Integration with People Wi-Fi (PL6741)

Do you have Amazon Alexa and a People Wi-Fi? You won't need anything else to control your system with your voice. You can integrate your Amazon Alexa into the Comelit video intercom system in just a few simple steps, without the help of a professional.

What do you need?

1. Own a configured and working Alexa device
2. Own the People Wi-Fi video intercom (**art.PL6741**)
3. Have the Comelit app installed on your smartphone, updated to the latest available version
4. Have the Amazon Alexa app installed on your smartphone

What functions can you manage?


- Receive information that someone has rung the doorbell
- If the face recognition functionality is active and the face of the person ringing the doorbell is registered in the list, you can receive information about WHO rang the doorbell.
- Open doors, gates or entrances with voice only
- If you have assigned actuators (for example “stair lights”) to the monitor buttons, you can activate them with your voice only



How can you use this functionality? Follow these simple steps:



1. Download/Update the Comelit app to the latest available version and pair your People Wi-Fi
2. Download the Amazon Alexa app and activate the Comelit Home skill
3. Configure interaction events (routines)

Procedure:

1. Open the Comelit app and log in
2. Select the icon in the top left and choose the Manage devices menu
3. Follow the procedure described below










Configure interaction events (routines)

Enable video intercom notifications to receive information that someone has rung the doorbell


Procedure:


1. Open the Amazon Alexa app
2. Enter the Devices section
3. Select Entry
4. Follow the procedure described below










Warning: Verify that the "Doorbell press announcements" option is enabled.
Then tap ←

















Type the text of the desired announcement.
Confirm it by tapping ✓.
Tap Next.



Select the device to play the announcement.
Tap Next





Configure interaction events (routines)

Enable interactions with Face Recognition functionality to receive information about WHO rang the doorbell

The Face Recognition function must be correctly configured on your People Wi-Fi

Procedure:

1. Open the Amazon Alexa app
2. Enter the Devices section
3. Instead of Entry, select one of the names of people enabled for the Face Recognition function that are shown
4. The procedure for creating the routine to be associated with the name is the same as described previously for the Entry device

